VScom Serial Device Servers: Through the web browser I have set a password for the NetCom config. Now when I try to access the configuration through a Web Browser it asks me for a username & password - what is the default username?

The username is empty, just enter the password

Unique solution ID: #1003
Author: Support
Last update: 2009-01-05 10:53

(c) 2024 VScom <service@visionsystems.de>
URL: https://faq.visionsystems.de/index.php?action=artikel&cat=3&id=4&artlang=en