

## *PCI/ISA/PCMCIA to Serial: My PCI serial card is not recognized under Linux - why?*

It could be that you have a newer card, which is not supported in the Linux mainline kernel. But we have a [patch](#) for the 2.6.33 version and it is a part of mainline kernel since version 2.6.35.

Here is a list of the newer cards:

PCI: 200I(-SI), 400I, 800I

PCI Express: 200E, 400E, 800E, 200EI(-SI), 400EH, 800EH

*Unique solution ID: #1060*

*Author: Support*

*Last update: 2013-11-21 12:58*