

CAN Adapters: How can I access CAN adapters from Java?

For now there is no vs_can_api DLL wrapper. Hence one can either use our DLL via [JNI interface](#) or use ASCII protocol with one of the [serial port communication libraries](#).

If your operating system is Linux, you can use a combination of slcand (from <https://github.com/linux-can/can-utils>), [socketcand](#) and Java classes from [Kayak](#).

Unique solution ID: #1099

Author: Support

Last update: 2019-12-03 11:56