

## *USB to Serial: Can I connect more than one USB-COM to my computer?*

**Yes.**--You may operate as many serial ports as your operating system supports. In

Windows 98/ME this is 128, in Windows 2000/XP it is 256. The limit in Linux is in the kernel,

you must change it there.

*Unique solution ID: #1010*

*Author: Support*

*Last update: 2009-01-05 10:48*