OnRISC: How to install and configure NFS server?

Execute

make menuconfig

and enable "File systems-›Dnotify"

and "File systems-›Network File Systems›NFS file system support" and support for NFS server either for NFS v3 or NFS v4

recompile and install the new kernel (see the following FAQ entry). In Debian create folder /lib/modules/2.6.26.5-1.0.0-vs/and an empty file /lib/modules/2.6.26.5-1.0.0-vs/modules.dep. After that install NFS utlities:

apt-get install nfs-kernel-server

After installation configure /etc/exports to enable NFS clients. See http://www.debianhelp.co.uk/nfs.htm for further details.

(c) 2026 VScom <service@visionsystems.de>
URL: https://faq.visionsystems.de/index.php?action=artikel&cat=4&id=47&artlang=en

OnRISC: How to install and configure NFS server?

Unique solution ID: #1046
Author: Support
Last update: 2010-12-20 12:18

(c) 2026 VScom <service@visionsystems.de>
URL: https://faq.visionsystems.de/index.php?action=artikel&cat=4&id=47&artlang=en