

## OnRISC: Where do I get kernel source for OnRISC devices?

Kernel source is provided on the DVD "Software". There is also [SVN repository](#) providing the newest kernel sources. For kernel compilation instructions see our [User Manual](#) .

Example (check out and compile kernel 2.6.33 for OnRISC Alekto):

- `svn co svn://svn.visionsystems.de/linux-2.6.33-OnRISC/trunk linux-2.6.33-OnRISC/trunk`
- `cd linux-2.6.33-OnRISC/trunk`
- `make onrisc_ks8695_defconfig`
- `make`

*Unique solution ID: #1005*

*Author: Support*

*Last update: 2010-12-20 11:54*